

New Style Corner Cap Installation



Remove the old cap, and clean the area free of caulk and butyl tape.



Place two strips of butyl tape along each side close to the edge, and under the top lip. Install screws snugged.



After all six screws have been snugged in, tighten all six. Careful not to apply too much force to any one screw.



Caulk the areas closed with an exterior grade caulk or silicone. Allow to dry.